

**Key:**

1. Optional screed to falls.
2. MASTERTOP® primers and preparation coats.
3. CONIROOF® waterproof membranes: select from systems 2110, 2111, 2103 or 2150.
4. Drainage layer with geotextile filter: CONIDRAIN® drainage board.

